

DM Gebouwbeheer-Domotica module tbv HRUC-E

Met deze module kunt u de ventilatiestanden van uw ventilatie-unit door een extern besturingssysteem zoals een gebouwbeheersysteem of een domoticasysteem laten schakelen. Standaard draait de unit in de lage ventilatiestand, doormiddel van het doorverbinden van de polen van de connector gemarkeerd met extern kunnen de 3 andere ventilatiestanden gekozen worden. Deze standen zijn: Vakantie-stand of uit-stand afhankelijk van de plaats van de jumper aan de achterkant, stand II en stand III.

Zet geen spanning op de module!

Deze module vervangt het “3-standenbedientableau” of “Luxe digitaal bedientableau”.



Gebruikersinstructie

De overige werking is gelijk aan dat van het “3-standen-bedientableau”, raadpleeg de handleiding van de unit.

De filters moeten schoon gemaakt of vervangen worden als de rode led continu brand. Knippert de LED raadpleeg dan de handleiding van de unit. Met de knop F kunt u na het reinigen of vervangen van de filters de filtertijd resetten, dit doet u door deze kop 10 seconden in te drukken.

DM Building Management-Domotica module for HRUC-E

This module allows you to control the ventilation speeds of your ventilation unit with an external control device like a building management system. Basically the unit runs in the slow ventilation speed. By connecting the poles of the connector, marked with extern, the 3 other ventilation speeds can be chosen. These speeds are: Holiday setting or off, depending on the setting of the jumper on the back, speed setting II and speed setting III. Don't put power on the module!

This module replaces the “Intelligent 3-position switch + LED indicator” or “Luxury digital control panel”.

User notes

The operation of this module is similar to that of the “Intelligent 3-position switch + LED indicator”, refer to the manual of the unit.

The filters needs to be cleaned/changed when the red LED burns continuously. If it blinks, see the manual of the unit for further details. By pressing the F button after cleaning or replacing the filters you can reset the filter timer (LED), press the buttons for 10 seconds.

Installatieschema
Installation drawing

